



Trailflap Installation Instructions

TF00-L - 12"x18" Plain Mud Flap System

TF00-J - 10"x14" Jeep Logo Mud Flap System

TF00-D - 10"x14" Diamond Mud Flap System

www.trailflap.com

Customer Service
425-205-8923

Parts Item List TF00- D, J, M:

- (1) Pair of 10"x14" Mud Flaps
- (2) Receiver Brackets
- (2) 22" Aluminum Hangers
- (2) Quick Pins
- (4) 5/16" Self Taping bolts
- (6) 1/4" Bolts
- (6) 1/4" Nylock Nuts
- (12) 1/4" Washers
- (2) End Caps

Parts Item List TF00L:

- (1) Pair of 12"x18" Mud Flaps
- (2) Receiver Brackets
- (2) 22" Aluminum Hangers
- (2) Quick Pins
- (4) 5/16" Self Taping bolts
- (8) 1/4" Bolts
- (8) 1/4" Nylock Nuts
- (16) 1/4" Washers
- (2) End Caps

1. Clean frame rails where mud flap receiver bracket will mount.
 2. Hold the mud flap, receiver bracket and aluminum hanger up against the frame rail like it would be installed. (Most Jeeps will mount with the receiver bracket up side down, holes below the hanger)
 3. Make sure there's enough clearance between the tire and mud flap / hanger.
 4. Mark two holes onto frame through the receiver bracket where you are going to drill your holes. (Try to install bolts diagonal)
 5. Look for any fuel and electrical lines before drilling.
 6. Drill holes with a **9/32" drill bit**.
 7. Install **(1) 5/16"** self tapping bolt into the receiver bracket and frame. (If installing onto a open channel frame we recommend using 5/16" bolts and nuts not supplied). Most Jeeps are a boxed frame and the self tapers are adequate,
 8. Insert aluminum hanger into receiver bracket and check level of hanger. Most frames have a curve or bevel to them so the hanger will not be level.
 9. Draw a line on the receiver bracket where it will need to be bent and remove Receiver bracket.
 10. Place the receiver bracket in a vise and bend the bracket with a pry tool (Not the aluminum hanger as it will do damage to the hanger). It's ok to bend the receiver bracket to far as it will be easy to bend back down once installed.
 11. Re-install receiver bracket with **(2) 5/16" bolts diagonal**. Careful not to over tighten bolts.
 12. Insert aluminum hanger with quick pin installed.
 13. Hold mud flap up to hanger where you will want the mud flap to be installed and mark hanger at the outer end of the mud flap.
 14. Remove hanger and cut with a hack saw.
 15. Drill out the pre set holes in the mud flap and set mud flap onto the hanger and mark holes.
 16. Drill holes through the aluminum hanger with a **1/4" drill bit**.
 17. Install bolts, washers, nylock nuts and end caps supplied.
 18. Insert mud flap installed on to the hanger with quick pin.
 19. Repeat same steps for other side of vehicle.
- Thank You for Purchasing the Trailflap Mud Flap System!

